## FlexSQUARE / LED Double Flash Beacon 853 LED Double Flash Beacon BWM 115-230VAC B



Part No.: 853.510.60



## **MECHANICAL DATA** Length 85 mm Width 85 mm Height 72 mm Materials PC PP-GF Dome colour Blue Housing colour Black Protection category IP66 IP67 Connection Screw terminals cross-sectional area maximum 1,50mm<sup>2</sup> / 16AWG Cable entry Membrane grommet Cable entry minimum d = 1 mmd = 6 mm Cable entry maximum d = 12 mm d = 9 mm Type of fixing Base mounting Wall mounting Working temperature minimum -25°C Working temperature maximum +50°C Weight with packaging 188 g Product weight 157 g **ELECTRICAL DATA** Operating voltage 115-230V Operating voltage type AC 50Hz at 230V Operating voltage frequency 60Hz at 115V Operating voltage tolerance +/- 10% Rated operational voltage 230 VAC Rated operational current 180 mA Rated inrush current 7.000 mA Protection class Protection class 2 Pollution degree 3 Overvoltage category Ш Ui = 250V; Uimp = 2.500V Isolation voltage **OPTICAL DATA** LED Light source Light colour Blue

For additional installation and mounting information, refer to the appropriate user guide at www.werma.com. This printed copy is for information only and is subject to alteration.

ļ


## FlexSQUARE / LED Double Flash Beacon 853 LED Double Flash Beacon BWM 115-230VAC B

Optical signal image	Double flash
Flash frequency	1 Hz
Service life optical	50,000 h maximum
APPROVAL DATA	
Conforms with CE	Yes
WEEE	Yes
Conform with ATEX-directive	No
Conforms with CCC	Yes
Conforms with UL	No
Conforms with FCC	No
Conforms with IC	No
EAC certificate available	Yes
Conforms with AS-I	No
ICAO Certification	No
Conforms with GL	No
Conforms with RoHS CN	No
Conforms with VdS	No

For additional installation and mounting information, refer to the appropriate user guide at www.werma.com. This printed copy is for information only and is subject to alteration.

i

## FlexSQUARE / LED Double Flash Beacon 853 LED Double Flash Beacon BWM 115-230VAC B



For additional installation and mounting information, refer to the appropriate user guide at www.werma.com. This printed copy is for information only and is subject to alteration.